

# ATTACHMENT LINE COUPLER KNX-301-DIN



## CONTENTS

1. SUMMARY.....	2
2. APPLICATION DESCRIPTION COUPLER.....	2
2.1. COUPLER.....	2
2.2. REPEATER.....	2
3. PARAMETER SETTING DESCRIPTION IN THE ETS.....	2
3.1. PCOUPLER .....	2
3.1.1. SETTING.....	2
3.1.2. PARAMETER WINDOW "GENERAL" .....	2
3.1.3. PARAMETER WINDOW "MAIN LINE" .....	3
3.1.4. PARAMETER WINDOW "SUB LINE" .....	3
3.2. REPEATER.....	4
3.2.1. SETTING.....	4
3.2.2. PARAMETER WINDOW "GENERAL" .....	4
3.2.3. PARAMETER WINDOW "MAIN LINE" .....	4
3.2.4. PARAMETER WINDOW "SUB LINE" .....	5



## 1. SUMMARY

The coupler can be used as line coupler, backbone coupler or repeater as well in existing EIB networks as in new KNX EIB networks. It has a filter table with the help of which bus telegrams are either blocked off from one of the two lines or are passed on to another line thus reducing the bus load. The filter table is created by the ETS (EIB Tool Software) automatically on commissioning the system.

As there are no differences in hardware between the line coupler, the backbone coupler and the repeater they were given the same ordering number.

The power supply of the coupler electronics occurs via the connection to the main line.

Used as a line coupler, The basic functionality of the coupler is coupling a KNX-TP-main line with a KNX-TP-sub line. The coupler provides galvanic isolation between the two connected lines. Due to the flexibility of the coupler, it can be used as a line coupler to connect a line to a main line or as a backbone coupler to connect a main line to a backbone line. The main task of the coupler is filtering the traffic according the installation place in the hierarchy or according to the built in filter tables for group oriented communication. The coupler provides outstanding features compared to other similar products, for example support for long messages (up to 250 byte length) and a configurable one button activation of special functions (e.g. transmit all group telegrams). These are helpful during installation, during run time and for trouble shooting. The high informative 6 du LED display shows accurate the bus status on each line. This helps identifying common communication problems due to bus load or re-transmissions on both lines.

Used as a repeater, its function has the target to link two lines for data transfer. And it still provides galvanic isolation between the connected lines. Up to three line repeaters can be used behind a line coupler. As a result, up to four lines can form a complete line. Each line must be supplied by a dedicated KNX power supply.

This manual provides the technical information about the coupler as well as assembly and programming in detail for users, and explains how to use the coupler by the application examples.

Application Programs:




Fig.1. Connection of repeaters to a bus line

The coupler can be programmed with the ETS up from version ETS2V11. Used as a line/backbone coupler the application program "**Coupler**" and used as a repeater the application program "**Repeater**" has to be downloaded.

Please note that commissioning straight at delivery status means:

- The line coupler does block all telegrams because the filter table is not defined.
- The fallback time after manual operation is 120 min and.
- The physical address is 15.15.0.

## 2. APPLICATION DESCRIPTION COUPLER

Application program	Max. number of communication objects	Max. number of group address	Max. number of associations
The line coupler/repeater	0	0	0

### 2.1. COUPLER

If the coupler receives telegrams (for example during commissioning) which use a physical address as destination address, it compares the physical addresses of the receiver with its own physical address and then decides whether it must route the telegrams or not.

The coupler reacts to telegrams with group addresses in accordance with its parameter settings. During normal operation (default setting), the coupler only routes those telegrams whose group addresses have been entered in its filter table.

If the coupler routes a telegram and does not receive an acknowledgement, or if a bus device finds a transmission error, the coupler repeats the telegram three times. With the parameters "**Repetitions if errors...**", this behaviour can be set separately for both lines. These parameters should be left in the default setting.

### 2.2. REPEATER

Line repeaters do not have any filter tables. This means that a telegram is sent to all lines irrespective of whether it is processed in the corresponding line. It is therefore not important whether the telegram has been triggered within the lines or whether it has been sent from the main line to the lines via the line coupler.

If an error occurs during the transmission of a telegram with the physical address of a receiver, the line repeater can repeat the telegram. This behaviour can be set separately for both line segments with the parameters "**Physical: Repetition if errors on main line/on sub line**".

If the line repeater routes a group telegram and does not receive an acknowledgement, or if a bus device finds a transmission error, the line repeater repeats the telegram three times. With the parameters "**Group: Repetition if errors on main line/on sub line**", this behaviour can be set separately for main line and sub line.


## 3. PARAMETER SETTING DESCRIPTION IN THE ETS

### 3.1. PCOUPLER

#### 3.1.1. SETTING

If not already configured as "**coupler**", the corresponding application program for "**coupler**" should be downloaded.

Change can occur under "**Change Application Program...**" and could be checked under "**Properties**:



#### 3.1.2. PARAMETER WINDOW "GENERAL"

Parameter window is shown as follow:




Fig.3.1: parameter window "General"

#### Parameter "Fallback time for manual operation"

Time duration required to exit from "manual operation".

- Options: 10 min
- 1 hour
- 4 hours
- 8 hours

#### Parameter "Manual function"

Telegram routing configuration for the manual function.

- Options: Disabled
- Pass all telegrams
- Pass physical telegrams
- Pass group telegrams

Please note that the parameter "transmit all" for Group or Physical telegrams is intended only for testing purposes and it should not be set for normal operation.

### 3.1.3. PARAMETER WINDOW "MAIN LINE"




Fig.3.2: parameter window "Main line"

#### Parameter "Configuration"

This parameter is to be set depending on the planned configuration.

- Options: groups: filter, physical: block
- groups, physical: filter
- groups: route, physical: filter
- groups, physical: route
- configure

Block: no telegram is routed.

Filter: Only telegrams are routed which are entered in the filter table.

Route: the telegrams are routed.

Configure: the following parameters can be set individually.

#### Parameter "Group telegrams"

- Options: transmit all (for testing only)
- block
- filter

Transmit all: All group telegrams are transmitted.

Block: No group telegram is transmitted.

Filter: Only group telegrams are routed which are entered in the filter table. The ETS 3/4 produces the filter table automatically.

#### Parameter "Main group telegrams 14/15"

- Options: transmit all
- block

Transmit all: Group telegrams with the main group 14 or 15 (e.g. 14/1) are routed.

Block: Group telegrams with the main group 14 or 15 (e.g. 14/1) are not routed.

#### Parameter "Physical telegrams"

- Options: transmit all (for testing only)
- block
- filter

Transmit all: All physical telegrams are transmitted.

Block: No physical telegram is transmitted.

Filter: Only physical telegrams are routed based on physical address.

#### Parameter "Physical: Repetition if errors on main line"

- Options: no
- normal
- reduced

If a transmission error (e.g. due to missing receiver) is found when sending a physical telegram on the main line:

No: The physical telegram is not repeated.

Normal: The physical telegram is repeated up to 3 times.

Reduced: The physical telegram will be repeated only one time.

#### Parameter "Group: Repetition if errors on main line"

- Options: no
- normal
- reduced

If a transmission error (e.g. due to missing receiver) is found when sending a group telegram on the main line:

No: The group telegram is not repeated.

Normal: The group telegram is repeated up to 3 times.

Reduced: The group telegram will be repeated only one time.

#### Parameter "Telegram confirmations on line"

- Options: if routed
- always

If routed: Only telegrams which are to be routed are confirmed on the main line (ACK).

Always: Each telegram on the main line is confirmed (ACK).

#### Parameter "Send confirmation on own telegrams"

- Options: yes
- no

Yes: Every telegram on the main line is confirmed with its own ACK (from the Line coupler).

No: No confirmation with own ACK

#### NOTE:

If the parameter "Send confirmation on own telegrams" is set yes, the line coupler will send an ACK systematically when sending any own routed telegram.

### 3.1.4. PARAMETER WINDOW "SUB LINE"




Fig.3.3: parameter window "Sub line"

#### Parameter "Configuration"

This parameter is to be set depending on the planned configuration.

- Options: groups: filter, physical: block
- groups, physical: filter
- groups: route, physical: filter
- groups, physical: route
- configure

Block: no telegram is routed.

Filter: Only telegrams are routed which are entered in the filter table.

Route: the telegrams are routed.

Configure: the following parameters can be set individually.

#### Parameter "Group telegrams"

- Options: transmit all (for testing only)
- block
- filter

Transmit all: All group telegrams are transmitted.

Block: No group telegram is transmitted.

Filter: Only group telegrams are routed which are entered in the filter table. The ETS 3/4 produces the filter table automatically.

#### Parameter "Sub group telegrams 14/15"

Options: transmit all  
block

Transmit all: Group telegrams with the sub group 14 or 15 (e.g. 14/1) are routed.

Block: Group telegrams with the sub group 14 or 15 (e.g. 14/1) are not routed.

#### Parameter "Physical telegrams"

Options: transmit all (for testing only)  
block  
filter

Transmit all: All physical telegrams are transmitted.

Block: No physical telegram is transmitted.

Filter: Only physical telegrams are routed based on physical address.

#### Parameter "Physical: Repetition if errors on sub line"

Options: no  
normal  
reduced

If a transmission error (e.g. due to missing receiver) is found when sending a physical telegram on the sub line:

No: The physical telegram is not repeated.

Normal: The physical telegram is repeated up to 3 times.

Reduced: The physical telegram will be repeated only one time.

#### Parameter "Group: Repetition if errors on sub line"

Options: no  
normal  
reduced

If a transmission error (e.g. due to missing receiver) is found when sending a group telegram on the sub line:

No: The group telegram is not repeated.

Normal: The group telegram is repeated up to 3 times.

Reduced: The group telegram will be repeated only one time.

#### Parameter "Telegram confirmations on line"

Options: if routed  
always

If routed: Only telegrams which are to be routed are confirmed on the sub line (ACK).

Always: Each telegram on the sub line is confirmed (ACK).

#### Parameter "Send confirmation on own telegrams"

Options: yes  
no

Yes: Every telegram on the sub line is confirmed with its own ACK (from the Line coupler).

No: No confirmation with own ACK

### 3.2. REPEATER

#### 3.2.1. SETTING

If not already configured as "repeater", the corresponding application program for "repeater" should be downloaded.

Change can occur under "Change Application Program..." and could be checked under "Properties":



#### 3.2.2. PARAMETER WINDOW "GENERAL"

Parameter window is shown as follow:




Fig.3.4: parameter window "General"

#### Parameter "Fallback time for manual operation"

Time duration required to exit from "manual operation".

Options: 10 min  
1 hour  
4 hours  
8 hours

#### Parameter "Manual function"

Telegram routing configuration for the manual function.

Options: Disabled  
Pass all telegrams  
Pass physical telegrams  
Pass group telegrams

Please note that the parameter "transmit all" for Group or Physical telegrams is intended only for testing purposes and it should not be set for normal operation.

#### 3.2.3. PARAMETER WINDOW "MAIN LINE"




Fig.3.5: parameter window "Main line"

#### Parameter "Configuration"

This parameter is to be set depending on the planned configuration.

Options: groups, physical: route  
configure

Route: the telegrams are routed.

Configure: the following parameters can be set individually.

#### Parameter "Physical telegrams"

Options: transmit all  
block

Transmit all: All physical telegrams are transmitted.

Block: No physical telegram is transmitted.

#### Parameter "Physical: Repetition if errors on main line"

Options: no  
normal  
reduced

If a transmission error (e.g. due to missing receiver) is found when sending a physical telegram on the main line:

No: The physical telegram is not repeated.

Normal: The physical telegram is repeated up to 3 times.

Reduced: The physical telegram will be repeated only one time.

#### Parameter "Group: Repetition if errors on main line"

Options: no  
normal  
reduced

If a transmission error (e.g. due to missing receiver) is found when sending a group telegram on the main line:

No: The group telegram is not repeated.

Normal: The group telegram is repeated up to 3 times.

Reduced: The group telegram will be repeated only one time.

#### Parameter "Telegram confirmations on line"

Options: if routed  
always

If routed: Only telegrams which are to be routed are confirmed on the main line (ACK).

Always: Each telegram on the main line is confirmed (ACK).

#### Parameter "Send confirmation on own telegrams"

Options: yes  
no

Yes: Every telegram on the main line is confirmed with its own ACK (from the Line coupler).

No: No confirmation with own ACK

#### Parameter "Send confirmation on own telegrams"

Options: yes  
no

Yes: Every telegram on the main line is confirmed with its own ACK (from the Line coupler).

No: No confirmation with own ACK

**NOTE:**

If the parameter "Send confirmation on own telegrams" is set yes, the repeater will send an ACK systematically when sending any own routed telegram.

Since the repeater has no filter table, it makes sense to send an ACK with every routed telegram.

#### 3.2.4. PARAMETER WINDOW "SUB LINE"




Fig.3.6: parameter window "Sub line"

#### Parameter "Configuration"

This parameter is to be set depending on the planned configuration.

Options: groups, physical: route  
configure

Route: the telegrams are routed.

Configure: the following parameters can be set individually.

#### Parameter "Physical telegrams"

Options: transmit all  
block

Transmit all: All physical telegrams are transmitted.

Block: No physical telegram is transmitted.

#### Parameter "Physical: Repetition if errors on sub line"

Options: no  
normal  
reduced

If a transmission error (e.g. due to missing receiver) is found when sending a physical telegram on the sub line:

No: The physical telegram is not repeated.

Normal: The physical telegram is repeated up to 3 times.

Reduced: The physical telegram will be repeated only one time.

#### Parameter "Group: Repetition if errors on sub line"

Options: no  
normal  
reduced

If a transmission error (e.g. due to missing receiver) is found when sending a group telegram on the sub line:

No: The group telegram is not repeated.

Normal: The group telegram is repeated up to 3 times.

Reduced: The group telegram will be repeated only one time.

#### Parameter "Telegram confirmations on line"

Options: if routed  
always

If routed: Only telegrams which are to be routed are confirmed on the sub line (ACK).

Always: Each telegram on the sub line is confirmed (ACK).